57


A fabrication process whereby air voids of different sizes and configurations are composed within a larger mass of dark grey glass. These air pockets are invisible when the piece is unlit, and come alive to reveal an interior universe when 57 is illuminated. By virtue of the method of making, each 57 is completely unique. A flexible suspension system enables pendants to be nestled in close-knit groups or loosely composed in a wider field, allowing each piece to be perceived individually.






57 random








BOCCI

Adjustable Lengths Cluster

canopies.




adjustable up to 3000 (10') standard


adjustable up to 24600 (80') custom




Ø152




Fixed Lengths Cluster canopies.




Ø501



57.37







57.61

fixed length up to 3000 (10') standard


fixed length up to 24600 (80') custom














adjustable up to 3000 standard adjustable 24600 custom

PENDANTS: three

MOUNTING: brass canopy 152mm (6") in diameter x 32mm (1.3")

deep

LAMPING: 1.8w LED (6w total)

CABLE: adjustable. 3000mm (10') standard / up to 24600mm

(80') maximum

MATERIALS: blown and dipped glass, cast borosilicate glass cap,

powder-coated steel and brass hardware, swag hooks, braided metal coaxial cable, aircraft cable, electrical

components.

WEIGHT: approximately 5kg (11lb)

TRANSFORMERS: integral

DESCRIPTION

57.3 is a random configuration of three 57 pendants hung from a round canopy. This fixture is designed to be horizontal, meaning that the pendants don't hang directly below, but instead trail off across a space, around a corner or simply deviate from their gravitational directive. As such, this fixture is designed to be hung from any number of optional swag points mounted elsewhere from the

57 is an exploration of a technique used for producing closed cell foam. The process involves trapping voids of air of different sizes and configurations within a glass matrix, yielding a shape loosely referencing a rain cloud. These pockets of air remain invisible when the piece is off, but come alive to reveal an interior universe when the piece is illuminated. By virtue of the fabrication process, each piece is completely unique.

NOTES

+ Purchase replacement lamps online at www.bocci.ca/lamps

EU Patent # 002268581-0001 to 0006 Worldwide patents issued and pending




Made in Vancouver. Canada


Berlin Vancouver


sales@bocci.ca europe@bocci.ca www.bocci.ca www.bocci.ca


approx 5kg (11lb)

















1

Very carefully uncoil the braided coaxial cable in a spool like manner. Insert your index fingers into opposite sides of the roll then rotate your fingers around each other to unroll the coaxial cable.

Use patience: allow the cable to uncoil completely to avoid kinks.

2

Thread the coaxial cables through the canopy, use a 2mm Allen key to loosen the setscrew in the canopy and gently feed the cable through until you have reached your desired drop length.

Use Allen key to tighten the setscrew to hold the strain relief and secure the coaxial cable at its new length. Perform a gentle tug test to ensure it is secure.

DO NOT OVERTIGHTEN.

Note: The strain relief is a black plastic collar around the coaxial cable. There is a single slot opening on the side of the strain relief component. It is essential that this opening is oriented at 90 degrees to set screw chamber. There can be no contact between the set screw and the cable.

RISK OF ELECTRIC SHORT!

3

LED: connect the black wire to black and white wire to white wire.

Connect the coaxial cable to the open slots in the terminal block on the 12V side of the transformers.

Ensure that the braided outer wires are all connected to one 12V output wire and all inner insulated wires are connected to the other or a short will occur.

Once all coaxial connections are made. lift the fixture into position and connect the line voltage to the open slot in the appropriate terminal block.

4

The client is responsible to ensure fasteners are attached to a robust structural substrate.

Tuck the transformer and wiring into the canopy. Line up the fastener holes or connect directly to structural ceiling surface using the fasteners provided.


Move pendant into location and mark the location for the swag hook screw on the ceiling.

6

Ensure that the ceiling at the swag location is strong enough to hold 2kg (5lbs) before attaching swag hook with the provided screws.

Thread the swag hook on to the mounting plate, ensuring all the threads are engaged.

Slide the ball end of the aircraft into the slot on the swag hook.






Remove the glass cap by turning counterclockwise and set aside.

Note: throughout the installation, be mindful not to damage the glass cap and do not lose track of it, its size was chosen specifically for this pendant.


Using a 2mm Allen key, loosen the set screw on the hardware. Insert the aircraft cable into the small hole.



9

Once the pendant is positioned at the desired height, tighten the set screw to lock in the aircraft cable.

Using wire cutters, trim off any excess aircraft cable.



10

Form a crook-shape in the coax right above the lampholder pinching it together over your index finger or thumb. The lampholder should be roughly 90 degrees to the rest of the length of coax

Bocci 1.8w LED lamps included.

Plug the lamp into the socket. Do not touch the lamp with your bare hands.

Purchase replacement lamps online at www.bocci.ca/lamps




Insert the lampholder into the pendant through the hole in the centre of the cap mount. Set it in such a way that the crook rests parallel to the cap mount and runs through the slot with the lampholder inside the pendant perpendicular to the cap mount

Put the cap back onto the pendant, ensuring that the coax remains seated in the slot. Thread the cap onto the mount.

DO NOT OVERTIGHTEN.

There should be a 2mm gap between the cap and the pendant with the coax emerging from inside.



12

Clean fingerprints from glass surfaces.

Turn fixture on.

For additional assistance, please contact Bocci:

Vancouver

sales@bocci.ca www.bocci.ca

Berlin

europe@bocci.ca www.bocci.ca


EU Patent # 002268581-0001 to 0006 Worldwide patents issued and pending


Made in Vancouver, Canada













up to 3000 (10') standard

up to 24600 (80') custom PENDANTS: three

MOUNTING: brass canopy 152mm (6") in diameter x 32mm (1.3")

deep

LAMPING: 1.8w LED (26w total)

CABLE: adjustable. 3000mm (10') standard / up to 24600mm

(80') maximum

MATERIALS: blown and dipped glass, cast borosilicate glass cap,

brass hardware and swag hooks, braided metal coaxial

cable, aircraft cable, electrical components.

WEIGHT: approximately 5kg (11lb)

TRANSFORMERS: integral

DESCRIPTION

57.3 is a cluster configuration of three 57 pendants suspended from a round canopy. This fixture is designed to be horizontal, meaning that the pendants don't hang directly below, but instead trail off across a space, around a corner or simply deviate from their gravitational directive. As such, this fixture is designed to be hung from any number of optional swag points mounted elsewhere from the canopy.

57 is an exploration of a technique used for producing closed cell foam. The process involves trapping voids of air of different sizes and configurations within a glass matrix, yielding a shape loosely referencing a rain cloud. These pockets of air remain invisible when the piece is off, but come alive to reveal an interior universe when the piece is illuminated. By virtue of the fabrication process, each piece is completely unique.

NOTES

+ Purchase replacement lamps online at www.bocci.ca/lamps

EU Patent # 002268581-0001 to 0006 Worldwide patents issued and pending

 ϵ



Made in Vancouver, Canada


Vancouver Berlin


sales@bocci.ca europe@bocci.ca www.bocci.ca www.bocci.ca


approx 5kg (11lb)





CLUSTER














1

Very carefully uncoil the braided coaxial cable in a spool like manner. Insert your index fingers into opposite sides of the roll then rotate your fingers around each other to unroll the coaxial cable.

Use patience: allow the cable to uncoil completely to avoid kinks.

2

Thread the coaxial cables through the canopy, use a 2mm Allen key to loosen the setscrew in the canopy and gently feed the cable through until you have reached your desired drop length.

Use Allen key to tighten the setscrew to hold the strain relief and secure the coaxial cable at its new length. Perform a gentle tug test to ensure it is secure.

DO NOT OVERTIGHTEN.

Note: The strain relief is a black plastic collar around the coaxial cable. There is a single slot opening on the side of the strain relief component. It is essential that this opening is oriented at 90 degrees to set screw chamber. There can be no contact between the set screw and the cable.

RISK OF ELECTRIC SHORT!

3

LED: connect the black wire to black and white wire to white wire.

Connect the coaxial cable to the open slots in the terminal block on the 12V side of the transformers.

Ensure that the braided outer wires are all connected to one 12V output wire and all inner insulated wires are connected to the other or a short will occur.

Once all coaxial connections are made, lift the fixture into position and connect the line voltage to the open slot in the appropriate terminal block.

4

The client is responsible to ensure fasteners are attached to a robust structural substrate.

Tuck the transformer and wiring into the canopy. Line up the fastener holes or connect directly to structural ceiling surface using the fasteners provided.

5


Move pendant into location and mark the location for the swag hook screw on the ceiling.

6

Ensure that the ceiling at the swag location is strong enough to hold 2kg (5lbs) before attaching swag hook with the provided screws.

Thread the swag hook on to the mounting plate, ensuring all the threads are engaged.

Slide the ball end of the aircraft into the slot on the swag hook.






Note: throughout the installation, be mindful not to damage the glass cap and do not lose track of it, its size was chosen specifically for this pendant.

Remove the glass cap by turning counter-

clockwise and set aside.


Using a 2mm Allen key, loosen the set screw on the hardware. Insert the aircraft cable into the small hole.



9

Once the pendant is positioned at the desired height, tighten the set screw to lock in the aircraft cable.

Using wire cutters, trim off any excess aircraft cable.



10

Form a crook-shape in the coax right above the lampholder pinching it together over your index finger or thumb. The lampholder should be roughly 90 degrees to the rest of the length of coax

Bocci 1.8w LED lamps included.

Plug the lamp into the socket. Do not touch the lamp with your bare hands.

Purchase replacement lamps online at www.bocci.ca/lamps



Insert the lampholder into the pendant through the hole in the centre of the cap mount. Set it in such a way that the crook rests parallel to the cap mount and runs through the slot with the lampholder inside the pendant perpendicular to the cap mount

Put the cap back onto the pendant, ensuring that the coax remains seated in the slot. Thread the cap onto the mount.

DO NOT OVERTIGHTEN.

There should be a 2mm gap between the cap and the pendant with the coax emerging from inside.



12

Clean fingerprints from glass surfaces.

Turn fixture on.

For additional assistance, please contact Bocci:

Vancouver

sales@bocci.ca www.bocci.ca

Berlin

europe@bocci.ca www.bocci.ca

EU Patent # 002268581-0001 to 0006 Worldwide patents issued and pending

Made in Vancouver, Canada








8



120/240V LED Driver - 4W



B-L03U-12V

PRIMARY: AC 100 - 240V, 120mA, 50/60Hz

SECONDARY: Max. 12V DC (4.2w max.)

LAMPING: 1w LED lamps: 1-3

1.5w LED lamps: 1-2 1.8w LED lamps: 1-2 2.3w ring LED lamps: 1

DIMMING: Non-dimmable

NOTES: Constant voltage

Class 2 power unit For LED lamps only

DIMENSION: 43mm (1.7") x 41mm (1.6") x 22mm (0.8")

DESIGNATION








SELV-equivalent

120/240V LED Driver - 8W



B-L07U-12V

PRIMARY: AC 100 - 240V, 170mA, 50/60Hz

SECONDARY: Max. 12V DC (8.4w max.)

LAMPING: 1w LED lamps: 1-7

1.5w LED lamps: 1-5 1.8w LED lamps: 1-4 2.3w ring LED lamps: 1-3

DIMMING: Non-dimmable

NOTES: Constant voltage

Class 2 power unit For LED lamps only

DIMENSION: 65mm (2.5") x 35mm (1.3") x 28mm (1.1")

DESIGNATION:






SELV-equivalent





ta: 50°C

120/240V LED Driver - 24W



B-L24U-12V

PRIMARY: AC 100 - 240V, 300mA, 60Hz

SECONDARY: Max. 12V DC (24w max.)

LAMPING: 1w LED lamps: 1-24

1.5w LED lamps: 1-16 1.8w LED lamps: 1-13 2.3w ring LED lamps: 1-10

DIMMING: Dimmable using minimum 8 lamps and improves with

larger load. Use low voltage electronic dimmers only

NOTES: Short Circuit Protection

Constant voltage Class 2 power unit For LED lamps only

DIMENSION: 42mm (1.7") x 170mm (6.7") x 33mm (1.3")

DESIGNATION






SELV-equivalent



For additional assistance, please contact Bocci:


Vancouver sales@bocci.ca www.bocci.ca Berlin europe@bocci.ca www.bocci.ca
















12.5 (0.5")

WATTAGE: 1.8w

2600k

CRI: 75 (100 is daylight)

LIGHT OUTPUT: 142 lumens

EFFICIENCY: 60 lm/w

LAMP LIFE: 25,000 hours

DESCRIPTION

The Bocci 1.8w LED lamping option offers a longer-life, energy efficient alternative to typical halogen or xenon lamps. This proprietary and worldwide patent pending design utilizes Bocci's standard G4 lamp holder (9.1mm/0.36" in diameter), which is designed to accept either the Bocci xenon lamp or the Bocci LED lamp. The possibility of dual usage allows the opportunity for existing chandeliers with xenon lamping to be retrofitted on site to LED along with the appropriate driver.

This unique replacement design is unlike typical embedded xenon fixtures as it eliminates the waste associated with catastrophic failures that leave no choice but to replace the entire fixture. When it comes time to relamp, the xenon heads may simply be replaced, as with conventional lamps. Bocci xenon lamp keeps the fixture out of landfills in the future, protects your investment and introduces a significant saving of energy.

NOTES

+ Purchase replacement lamps online at www.bocci.ca/lamps

RoHS (€

Vancouver sales@bocci.ca www.bocci.ca

Berlin europe@bocci.ca www.bocci.ca